

DIAGNOSTICA SEGNALAZIONE ERRORI

SEGNALE (LED/BUZZER)	Significato	Soluzione
bip intermittente	Fine acqua tanica esterna	Rabboccare acqua in tanica
bip fisso	Mancato caricamento acqua	Spegnere e riaccendere , scaricare pressione della caldaia, inserire tubi blu in tanica verificando pescaggio. Se persiste rivolgersi Centro assistenza autorizzato
4 bip / pausa 4"	Mancata richiesta caricamento acqua	Eseguire pulizia della caldaia. Se persiste rivolgersi Centro assistenza autorizzato
2 bip una volta sola	Standby dopo 30 min di inutilizzo con interruttore caldaia acceso (on)	Erogare vapore

MALFUNCTIONS SELF-DIAGNOSTIC

SIGNAL (LED/BUZZER)	Meaning	Solution
Intermittent beep	End of external tank water	Fill in the tank with water
Permanent beep	Missing water filling	Switch off and on, Release boiler pressure, Insert blue hoses in the tank and check their suction capacity. If the problem persists, contact an authorised Service Centre.
4 beeps / 4" pause	Missing water filling request	Clean the boiler. If the problem persists, contact an authorised Service Centre.
2 beeps only once	Standby after 30 min inactivity with boiler switch on	Supply steam.