

IT

## DIAGNOSTICA

SEGNALE (LED/BUZZER)	Significato	Soluzione
bip fisso	Fine acqua tanica esterna	Rabboccare acqua in tanica
	Mancato caricamento acqua	Spegnere e riaccendere , scaricare pressione della caldaia, inserire tubi blu in tanica verificando pescaggio. Se persiste rivolgersi Centro assistenza autorizzato
4 bip / pausa 4"	Mancata richiesta caricamento acqua	Spegnere e riaccendere. Se persiste rivolgersi Centro assistenza autorizzato
2 bip una volta sola	Standby dopo 30 min di inutilizzo con interruttore caldaia acceso (on)	Erogare vapore

**NOTA:** Questo macchina è sprovvista di Sonda di pescaggio , fig. 2 , posizione (19)

IT

## DIAGNOSTICA

SEGNALE (LED/BUZZER)	Significato	Soluzione
bip fisso	Fine acqua tanica esterna	Rabboccare acqua in tanica
	Mancato caricamento acqua	Spegnere e riaccendere , scaricare pressione della caldaia, inserire tubi blu in tanica verificando pescaggio. Se persiste rivolgersi Centro assistenza autorizzato
4 bip / pausa 4"	Mancata richiesta caricamento acqua	Spegnere e riaccendere. Se persiste rivolgersi Centro assistenza autorizzato
2 bip una volta sola	Standby dopo 30 min di inutilizzo con interruttore caldaia acceso (on)	Erogare vapore

**NOTA:** Questo macchina è sprovvista di Sonda di pescaggio , fig. 2 , posizione (19)

EN

## DIAGNOSTICS

SIGNAL (LED/BUZZER)	Meaning	Solution
Fixed beep	No water in external tank	Top up water in tank
	No water filling	Turn on and off, release boiler pressure, insert blue hoses in tank checking priming. If persists, contact an authorised service centre
4 beeps / 4" pause	No water filling request	Turn on and off. If persists, contact an authorised service centre
2 beeps once	Standby after 30 min of inactivity with boiler switch ON	Supply steam

**NOTE:** This machine is without Priming sensor, fig. 2 position (19).

7.400.0235-00

EN

## DIAGNOSTICS

SIGNAL (LED/BUZZER)	Meaning	Solution
Fixed beep	No water in external tank	Top up water in tank
	No water filling	Turn on and off, release boiler pressure, insert blue hoses in tank checking priming. If persists, contact an authorised service centre
4 beeps / 4" pause	No water filling request	Turn on and off. If persists, contact an authorised service centre
2 beeps once	Standby after 30 min of inactivity with boiler switch ON	Supply steam

**NOTE:** This machine is without Priming sensor, fig. 2 position (19).

7.400.0235-00